

## Installation of your boot-bag Elise



Your boot-bag will come with the standard straps, shoulder strap and 4x1M straps with hooks on. Select one of the shorter standard straps and thread this around the bonnet hinge as shown make sure this goes round the hinges/hinge, thread back up over the engine cover so you have two ends. You can discard the other straps. You may want to cut this to length and melt the ends with a flame to stop any fraying.



Lay the protective anti slip matting on the car as far away as possible from vents towards the rear of the car.



Place boot-bag on the matting, ensure zip facing away from wind logo is rear right & flap is down. The bag has 6 ladder lock fixings on the top for the ends of the straps. Attach the two ends from the engine bay to the rear two ladder-locks on the bag and then attach straps with hooks to sides and rear of the bag. Ensure hooks fully round lip of wheel arches once tight.



The straps attach to the bag with 6 ladder-lock buckles, ensure they are tight, its critical that the straps are attached as shown, the strap should be threaded up away from the boot-bag via the wider slot towards the front of the buckle, thread the same end back towards the boot-bag through the narrower opening and pull tight. We recommend you stop after 5 miles or so to re-tighten the straps as the contents of the boot-bag will have settled, thanks for buying a boot-bag for your Lotus Elise.